Operating Instructions

BRINKMANN Immersion Pumps

STA/SAL630…1303

BRINKMANN PUMPS, Inc.
47060 Cartier Drive
Wixom, MI 48393
USA

Phone: +1 248 926 9400
Fax.: +1 248 926 9405

www.brinkmannpumps.com
sales@brinkmannpumps.com

Subject to change without prior notice.

Order - No.: BAS6500 ENGLISH

© Brinkmann Pumps, Inc.
Edition 08/2015

Brinkmann Immersions Pumps of the Series STA/SAL630 ... 1303

Contents

1 Indication to the manual 2
2 Description of the Product 2-4
3 Safety instructions 4-5
4 Transportation and Storage 5
5 Installation and Connection 6
6 Start-up / Shut-down 7
7 Operation 7
8 Servicing and Maintenance 7
9 Troubleshooting Guide 8
10 Spare Parts 9-10
11 Repair 10
12 Disposal 10
13 WARRANTY 11

1 Indication to the manual

This operating manual gives basic instructions which are to be observed during installation, operation and maintenance of the pump. It is therefore imperative that this manual be read by the responsible personnel and operator prior to assembly and commissioning. It is always to be kept available at the installation site.

1.1 Identification of safety instructions in the operating manual

Safety instructions given in this manual non-compliance with which would affect **safety** are identified by the following symbol

Safety sign according with ISO 3864 – B.3.1

or where **electrical safety** is involved, with:

Safety sign according with ISO 3864 – B.3.6

Where non-compliance with the safety instructions may cause a risk to the machine and it's function the word

ATTENTION

is inserted.

2 Description of the Product

2.1 General description of the pump

Pumps of this type are one or multi-stage rotary pumps where the impellers are fixed on the driving shaft extension. The pump shaft and motor shaft are interconnected by means of a shaft clamp. Pump and motor form a compact and space-saving unit. These pumps are fitted out with semi-open impellers, (and a suction screw SAL construction).

Vertically mounted pumps are equipped with a mounting flange. The pump end immerses into the tank and the motor extends vertically above the tank.

2.2 Intended use

The immersion pumps of the series STA/SAL are suitable for handling contaminated coolants within the limiting application in accordance with table 1. The pumps of SAL are suitable for handling extremely inflated fluids.

Limit of Application (Table 1)

Type	STA/SAL630...1303
Mediums	Coolant, cooling- and cutting-oils
Kinetic viscosity of the medium	…200 SSU *(...45 mm^2/s)*
Temperature of medium	30 … 175 °F *(0 ... 80 °C)*
Particle-size in the medium	0.35 Inches *(9 mm)* STA/SAL630, 901…904 0.47 Inches *(12 mm)* STA/SAL1001…1004 0.55 Inches *(14 mm)* STA/SAL830, 1301…1303
min. delivery volume	1% of Q max.
Dry running	Dry running causes increased wear and should be avoided. During the test of the direction of rotation (< 30 s) permissible.
Motor cycle time per hour	Motors less 4.0 HP max. 200 from 4.0 HP to 5.4 HP max. 40 from 6.7 HP to 14 HP max. 20 from 15.0 HP and higher max. 15
Ambient temperature	104 °F *(40 °C)*
Set-up altitude	3280 ft *(1000 m)*

ATTENTION

The pumps are to be operated within their design limits. Applications outside of these limits are not approved. The manufacturer is not responsible for any damages resulting from use of the pumps in such applications.

2.3 Technical data

Type		Type		Max. del. pressure spec. weight 1 PSI	*bar*	Max. del. volume GPM	*l/min*	Height **H** **I**nches *mm*	Depth of immersion STA[1] **h** Inches	*mm*	Weight STA[2] **g** lbs	*kg*	Power HP *kW*	Noise level STA[3] dBA / 60 Hz
STA630S	200	SAL630S	220	48	*3.3*	310	*1175*	18.4	7.87	*200*	159	*72*	5.4	73
	300		320					*468*	11.81	*300*	165	*75*	*4.0*	
	430		450						16.93	*430*	172	*78*		
	550		570						21.65	*550*	181	*82*		
	750		770						29.52	*750*	190	*86*		
	980		1000						38.58	*980*	205	*93*		
STA830S	210	SAL830S	230	48	*3.3*	410	*1550*	18.4	8.27	*210*	161	*73*	5.4	74
	310		330					*468*	12.20	*310*	168	*76*	*4.0*	
	440		460						17.32	*440*	174	*79*		
	560		580						22.05	*560*	183	*83*		
	760		780						29.92	*760*	192	*87*		
	990		1000						38.98	*990*	209	*95*		
	1110		1130						43.70	*1110*	216	*98*		
STA901S	200	SAL901S	220	36	*2.5*	290	*1100*	16.9	7.87	*200*	108	*49*	3.5	71
	300		320					*429*	11.81	*300*	113	*51*	*2.6*	
	430		450						16.93	*430*	117	*53*		
	550		570						21.65	*550*	124	*56*		
	750		770						29.53	*750*	135	*61*		
	980		1000						38.58	*980*	150	*68*		
	1100		1120						43.31	*1100*	159	*72*		
STA902S	270	SAL902S	290	70	*4.9*	310	*1150*	19.8	10.63	*270*	181	*82*	7.4	74
	370		390					*504*	14.56	*370*	187	*85*	*5.5*	
	500		520						19.68	*500*	196	*89*		
	620		640						24.41	*620*	205	*93*		
	820		840						32.28	*820*	216	*98*		
	1050		1070						41.34	*1050*	232	*105*		
	1170		1190						46.06	*1170*	249	*113*		
STA903S	340	SAL903S	360	100	*7.0*	315	*1190*	24.1	13.38	*340*	260	*118*	13.8	78
	440		460					*612*	17.32	*440*	267	*121*	*10.3*	
	570		590						22.44	*570*	276	*125*		
	690		710						27.16	*690*	284	*129*		
	890		910						35.04	*890*	295	*134*		
	1120		1140						44.09	*1120*	311	*141*		
STA904S	410	SAL904S	430	132	*9.1*	320	*1200*	24.4	16.14	*410*	318	*144*	17	79
	510		530					*620*	20.07	*510*	324	*147*	*12.6*	
	640		660						25.19	*640*	333	*151*		
	760		780						29.92	*760*	342	*155*		
	960		980						37.79	*960*	353	*160*		
	1190		1210						46.85	*1190*	364	*165*		
STA1001S	210	SAL1001S	230	33	*2.3*	320	*1200*	16.9	8.27	*210*	110	*50*	3.5	70
	310		330					*429*	12.20	*310*	115	*52*	*2.6*	
	440		460						17.32	*440*	119	*54*		
	560		580						22.05	*560*	126	*57*		
	760		780						29.92	*760*	137	*62*		
	990		1010						38.98	*990*	152	*69*		
	1110		1130						43.70	*1110*	161	*73*		
STA1002S	290	SAL1002S	310	63	*4.4*	350	*1325*	19.8	11.42	*290*	183	*83*	7.4	73
	390		410					*504*	15.35	*390*	190	*86*	*5.5*	
	520		540						20.47	*520*	198	*90*		
	640		660						25.20	*640*	207	*94*		
	840		860						33.07	*840*	218	*99*		
	1070		1090						42.13	*1070*	234	*106*		
	1190		1210						46.85	*1190*	245	*111*		

Type	Type	Max. del. pressure spec. weight 1 PSI	*bar*	Max. del. volume GPM	*l/min*	Height **H** Inches *mm*	Depth of immersion STA[1] **h** Inches	*mm*	Weight STA[2] **g** lbs	*kg*	Power HP *kW*	Noise level STA[3] dBA / 60 Hz
STA1003S 370	SAL1003S 390	92	*6.2*	360	*1350*	24.1	14.57	*370*	262	*119*	13.8	76
470	490					*612*	18.50	*470*	269	*122*	*10.3*	
600	620						23.62	*600*	278	*126*		
720	740						28.35	*720*	287	*130*		
920	940						36.22	*920*	298	*135*		
1150	1170						45.28	*1150*	313	*142*		
STA1004S 450	SAL1004S 470	120	*8.5*	370	*1400*	24.4	17.72	*450*	331	*150*	20	79
550	570					*620*	21.65	*550*	337	*153*	*15.0*	
680	700						26.77	*680*	346	*157*		
800	820						31.50	*800*	355	*161*		
1000	1020						39.37	*1000*	366	*166*		
1230	1250						48.43	*1230*	381	*173*		
STA1301S 210	SAL1301S230	34	*2.4*	385	*1480*	18.4	8.26	*210*	126	*57*	5.4	73
310	330					*468*	12.20	*310*	130	*59*	*4.0*	
440	460						17.32	*440*	135	*61*		
560	580						22.04	*560*	141	*64*		
760	780						29.92	*760*	152	*69*		
990	1010						38.97	*990*	168	*76*		
1110	1130						43.70	*1110*	174	*79*		
STA1302S 290	SAL1302S310	65	*4.5*	420	*1560*	24.1	11.42	*290*	238	*108*	11.5	78
390	410					*612*	15.35	*390*	245	*111*	*8.6*	
520	540						20.47	*520*	254	*115*		
640	660						25.19	*640*	262	*119*		
840	860						33.07	*840*	273	*124*		
1070	1090						42.12	*1070*	289	*131*		
STA1303S 370	SAL1303S390	100	*6.8*	440	*1680*	24.4	14.56	*370*	304	*138*	17	79
470	490					*620*	18.50	*470*	311	*141*	*12.6*	
600	620						23.62	*600*	324	*147*		
720	740						28.34	*720*	329	*149*		
920	940						36.22	*920*	340	*154*		
1150	1170						45.28	*1150*	355	*161*		

1) **Depth of immersion SAL = h + 0.78 Inches *(20 mm)***

2) **Weight SAL = g + 4.4 lbs *(2 kg)* for STA/SAL630, 830 and g + 2.2 lbs *(1 kg)* for STA/SAL901…1303**

3) Noise emissions measured in accordance with DIN 45635 at a distance of 39.37 Inches *(1 m).*

The motor is surface-cooled and compliant with
DIN IEC 34 and EN 60034 (protection degree IP 55).

3 Safety instructions

When operating the pump, the safety instructions contained in this manual, the relevant national accident prevention regulations and any other service and safety instructions issued by the plant operator are to be observed.

3.1 Hazards in the event of non-compliance with the safety instructions

Non-compliance with the safety instructions may produce a risk to the personnel as well as to the environment and the machine and results in a loss of any right to claim damages.
For example, non-compliance may involve the following hazards:

- Failure of important functions of the machines/plant
- Failure of specified procedures of maintenance and repair
- Exposure of people to electrical, mechanical and chemical hazards
- Endangering the environment due to hazardous substances being released

3.2 Unauthorized modes of operation

- Pump may not be used in potentially explosive environments**!**
- Pump and discharge piping are not designed to hold any weight and may not be used as a step ladder.

3.3 Remaining Risk

Risk of Injury!
Risk of squeezing or crushing body parts when installing or removing the pump exists. Proper and secured lifting tools must be used.

Risk of burns!
The pump must have cooled down sufficiently prior to commencing any repair, maintenance or installation.

3.4 Qualification and training of operating personnel

The personnel responsible for operation, maintenance, inspection and assembly must be adequately qualified. Scope of responsibility and supervision of the personnel must be exactly defined by the plant operator. If the staff does not have the necessary knowledge, they must be trained and instructed, which may be performed by the machine manufacturer or supplier on behalf of the plant operator. Moreover, the plant operator is to make sure that the contents of the operating manual are fully understood by the personnel.

3.5 Safety instructions relevant for operation

- If hot or cold machine components involve hazards, they must be guarded against accidental contact.
- Guards for moving parts (e.g. coupling) must not be removed from the machine while in operation.
- Any leakage of hazardous (e.g. explosive, toxic, hot) fluids (e.g. from the shaft seal) must be drained away so as to prevent any risk to persons or the environment. Statutory regulations are to be complied with.
- Hazards resulting from electricity are to be prevented (see for example, the VDE Specifications and the bye-laws of the local power supply utilities).
- The pumps' stability against falling over is not ensured unless it is properly mounted onto the tank.
- The female threads on the motor MUST NOT be used to lift the entire pump and motor assembly.

3.6 Safety instructions relevant for maintenance, inspection and assembly work

Any work on the machine shall only be performed when it is at a standstill, it being imperative that the procedure for shutting down the machine described in this manual be followed.
Pumps and pump units which convey hazardous media must be decontaminated.
On completion of work all safety and protective facilities must be re-installed and made operative again.
Prior to restarting the machine, the instructions listed under "Start up" are to be observed.

3.7 Signs on the pump

It is imperative that signs affixed to the machine, e.g.:

- arrow indicating the direction of rotation
- symbols indicating fluid connections

be observed and kept legible.

3.8 Unauthorized alterations and production of spare parts

Any modification may be made to the machine only after consultation with the manufacturer. Using spare parts and accessories authorized by the manufacturer is in the interest of safety. Use of other parts may exempt the manufacturer from any liability.

4 Transportation and Storage

Protect the pump against damage when transporting.
The pumps may only be transported in a horizontal position and hooks or straps must be attached on the motor and pump end.
Do not use the pump shaft for connecting any transportation aids such as hooks or straps.
Pumps must be drained prior to their storage.
Store pump in dry and protected areas and protect it against penetration of foreign bodies.
Always store pump above the freezing point!

5 Installation and Connection

5.1 Mechanical installation

During any assembly or disassembly process the pumps must be secured against tipping trough ropes for example at all times.

Pumps must be mounted securely. Piping, tank and pumps must be mounted without any tension.

The inlet is at the bottom of the immersed pump body. The distance between the inlet and the tank bottom must be so large that the inlet can not be blocked by deposits during longer shutdowns.

To obtain the full flow rate it is recommended to choose for the pipework the nominal bore diameter of the pumps cross section for connection. Therefore pipe bends should be used, not pipe angles!

The pipework must be qualified for occuring hydraulic pressure.



Dimensions in Inches (mm);
*) Dimensions for STA630, 830, 901, 1001, 1301
**) Dimensions for STA904, 1004, 1303

ATTENTION

Maximum tightening torque for piping connections is 150 ft. lbs. *(200 Nm)*!

When installed the space around the pump must be large enough to provide sufficient cooling of the motor.

Do not prop up the pressure line via the joining socket.

The pump must be mounted in that way that rotating parts under the cover of the coolant tank can not be touched!

5.2 Electric wiring

All service work must be carried out by qualified service personnel. Pump must be disconnected from the power source and all rotating parts must stand still. Reassure that pump is disconnected from power source and cannot be switched on. Verify that there is no voltage at the terminal board!

According to the European Standard EN809 a motor overload must be installed and properly set to the full load amps stated on the pump name plate.

It is the responsibility of the machine operator to decide whether or not an additional emergency switch must be installed.

5.2.1 Circuit

Tension voltage and frequency must correspond with the shown specification on the nameplate.

The pump must be wired so that a solid longterm electrical connection is ensured. Establish a solid ground connection.

The electrical wiring must be performed according to the wiring diagram shown inside the terminal box cover. (Please see above sample wiring diagrams)

Wiring diagram e.g.

Up to 13.8 HP
Voltage changing 1:2 YY / Y
e.g. 230 / 460 V, 60 Hz



YY
Low Voltage



Y
High Voltage



17 Hp and higher
Delta connection
3 x 460 V, 60 Hz

There may be no foreign objects such as dirt, particles or humidity inside the terminal board.

Mount terminal board cover to motor tight against dust and humidity and close up all unused wiring ports.

ATTENTION

When Variable Frequency Drives are used interfering signals might occur.
Non-sinus shaped supply voltage from a variable frequency drive might result in elevated motor temperatures.

6 Start-up / Shut-down

6.1 Start-up

ATTENTION

Switch off at the mains.
After connection the electrical wires, close the terminal box. Briefly start the motor (max. 30 sec.) and check the rotation according to the arrow on the top of the motor.
If the direction is incorrect change over two of the power leads.

6.2 Shut-down

All service work must be carried out by qualified service personnel. Pump must be disconnected from the power source and all rotating parts must stand still. Reassure that pump is disconnected from power source and cannot be switched on. Verify that there is no voltage at the terminal board!
Open terminal box and disconnect the power leads.
Empty out the pump.

7 Operation

Liquid level

According to the drawing shown below, the maximum liquid level must stay about 1.18 Inches *(30 mm)* below the mounting flange, also ensure that the minimal liquid level for the STA pump is 2.36 Inches *(60 mm)* before starting up the motor, for the SAL pump the suction hole of the pump body must be covered with liquid.



Dimensions in Inches (mm)

If the pump should lock up and cease, shut pump down (see 6.2) and disconnect from power supply. Pump must be uninstalled and removed from the system prior to its repair.

8 Servicing and Maintenance

ATTENTION

The surface of the motor must be kept free of dirt.

The motor shaft is spinning in permanently greased ball bearings (with special grease and increased bearing play) and does not require any special maintenance.

9 Troubleshooting Guide

Fault	Cause	Remedy
Motor does not start, no motor noise	At least two of the power supply leads have failed Overload has tripped	Check fuses, terminals and supply leads . Inspect overload
Motor does not start, humming noise	One of the supply leads has failed Impeller faulty Motor bearing faulty	See above Replace impeller Replace bearing
Overload trips	Pump locked up mechanically High on/of cycling frequency	Inspect pump hydraulics Check application
Power consumption is too high	Wrong direction of rotation of impeller Lime or other deposits mechanical friction	See above Clean pump mechanism repair pump
Motor overheats	High on/off cycling frequency Wrong power supply (voltage or cycles) Insufficient cooling	See above Power supply must correspond with name plate rating Check air flow at motor fan
Pump does not pump	liquid level too low Pump mechanism faulty Pipe blocked	Fill up liquid replace pump mechanism Clean pipe
Insufficient flow and pressure	Wrong direction of rotation of impeller Pump mechanism silted up Worn pump mechanism	Change over two power supply leads Clean pump mechanism Replace pump mechanism
Incorrect flow or pressure	Wrong power supply (voltage or cycles)	Power supply must correspond with name plate rating
Running noise/Vibration	Foreign objects in pump end Impeller damaged Bearing/Bushing broken	Remove foreign objects Replace impeller Replace bearing/bushing

10 Spare Parts

10.1 Spare Part List for the Immersion Pumps of the Series STA/SAL630 ... 1303



Item	Description	
1	Stator with terminal board	
2	Motor flange	
3	End shield	
4	Terminal box up to 5.4 HP	
5	Terminal box frame up 7.4 HP	
6	Terminal box cover up 7.4 HP	
7	Fan	
8	Fan cover	
9	Ball bearing	DIN 625
9	Ball bearing 1.75…3.5 HP and up 10 HP	DIN 628
10	Ball bearing	DIN 625
11	Gasket	
12	Gasket up 7.4 HP	
13	Retaining ring	
13	Retaining ring 1.75…3.5 HP	DIN 471
14	Thread rolling screw	DIN 7500
15	Slotted cheese head screw	DIN 84
16	Socket head cap screw	DIN 912
17	Socket head cap screw	DIN 912
18	Nut from 16 HP and over	DIN 934
19	Parallel pin	DIN 7
20	Shaft seal	
21	Retaining ring up to 7.4 HP	DIN 472
22	Retaining ring up to 7.4 HP	DIN 471
23	Compensation disk	
24	Shaft seal	
25	O-ring	
26	Shaft seal from 10 HP and over	
28	Bearing cover 10 HP and over	
29	Socket head cap screw 10 HP and over	DIN 931
30	Shaft nut 10 HP and over	
50	Pump body	
51	Shaft with rotor	
52	Inlet cover for STA	
52	Intake cover for SAL	
53	Pump plate up STA/SAL902, 1002. 1302	
55	Impeller	
57	Suction screw only for SAL	
58	Extension pump body up 29.5 Inches *(750 mm)* depth of immersion	
59	Distance liner	
60	Distance liner	
61	Running sleeve	
62	Bearing bush	
63	Distance plate	
64	Woodruff key	DIN 6888
66	O-ring up 29.5 Inches *(750 mm)* depth of immersion	
67	O-ring	
68	Splash ring	
69	Splash ring	
72	Socket head cap screw up	DIN 912
74	Stud bolt STA/SAL1302...1303	
75	Hexagon domed cap nut STA/SAL1302...1303	DIN 1587
77	Hexagon thin nut STA	DIN 439
78	Socket head cap screw up 29.5 Inches (*750 mm)* depth of immersion	DIN 912
82	Joining socket	
83	Socket head cap screw	DIN 912
84	Spring washer	DIN 7980
85	O-ring	
86	Screw plug	DIN 908
87	Sealing ring	DIN 7603
88	Serrated lock washer	
89	Flat head screw	DIN 7991
90	Adapter from 16 HP and over	
91	Extension shaft up 29.5 Inches *(750 mm)* depth of immersion	
92	Insert shaft	
93	Shaft clamp 2 x up 29.5 Inches *(750 mm)* depth of immersion	

10.2 Indications to the spare part order

Spare parts are available from the supplier.
Standard commercially available parts are to be purchased in accordance with the model type.
The ordering of spare parts should contain the following details:

1. **Pumptype**
   e.g. STA1302S520
2. **Pump No.**
   e.g. 08156500
   The date of the construction year is a component of the pumps type number.
3. **Voltage, Frequency and Power**
   Take item 1, 2 and 3 from the nameplate
4. **Spare part with item No.**
   e.g. Intake cover item No. 52

11 Repair Instructions / Replacing shaft clamps and shafts



1 = Shaft clamp
2 = Insert / extension shaft
3 = Motor shaft / Insert shaft

11.1 Dismantling the insert shaft or extension shaft

– Disconnect the submergible pump from the mains both electrically and mechanically.
– Remove pump from system. Secure pump against tipping over, i.e. use ropes to secure pump.
– Set the pump down on the fan cover. Dismantle the pump unit and the extension pump body (if appropriate).

Wear safety gloves!
Risk of injury due to sharp edges on pump components, i.e. impeller blades.

– Loosen the screws on the shaft clamp (1) one after the other.

Do not, under any circumstances, remove the screws completely, **danger of injury!**

– Remove the extension shaft (2) and shaft clamp (1).
– Dismantle the pump body.
– Loosen the screws on the shaft clamp (1) (see above), pull the insert shaft (2) off the motor shaft (3).

11.2 Assembling the insert shaft and motor shaft

ATTENTION

Clean the contact surfaces of the insert shaft (2) (inside) and the motor shaft (3). They must not be lubricated or oiled.

– Set the motor down on the fan cover.
– Position the shaft clamp (1) (use a new shaft clamp) in the centre of the cranked clamping diameter (2) of the insert shaft.
– Insert the motor shaft (3) into the insert shaft (2).
– **Tighten**:
  Mark the first screw and tighten all the screws evenly by hand, one after the other in a clockwise direction (not cross-ways).

- up to 17 HP
  Use a torque screwdriver to tighten each screw first with 1.5 ft. lbs. *(2 Nm)* then with 2.6 ft. lbs. *(3.5 Nm)* and finally with 3.7 ft. lbs. *(5 Nm)* (in a clockwise direction again).
- > 17 HP
  Use a torque screwdriver to tighten each screw first with 1.5 ft. lbs. (2 Nm) then with 5.3 ft. lbs. (7 Nm) and finally with 9 ft. lbs. (12 Nm) (in a clockwise direction again)
- Mount the pump body.
- In the case of pumps with an extension body, the assembly and tightening of the second shaft clamp is carried out as before.

The remainder of the reassembly process is to be completed in the opposite order of the prior described dismantling process.

ATTENTION

Note torques for the screw connections!

When putting the pump back into use, **make sure the direction of rotation is correct!**

Tightening torques for screwed connections

Thread - ∅	**M5**	**M8**	**M10**	**M16**	**M16**
Strength classes	4.8	8.8	10.0	8.8	
Tightening torque ft. lbs. *(Nm)*	**2.2** ***(3)***	**15** ***(20)*** **3.3** ***(4.5)*** Item 3	**22** ***(30)*** Item.18	**44.3** ***(60)*** Item.83	**44.3** ***(60)*** Item.77

12 Disposal

When disposing of the pump or the packaging materials the local and national regulation for proper disposal must be complied with.
Prior to its disposal, the pump must be completely drained and decontaminated if necessary.

13 WARRANTY

Brinkmann Pumps, Inc. warrants that the product contained herein conforms to the description in Brinkmann's catalog and that if this product shall fail to conform to the description thereof or to any express or implied warranty, Brinkmann shall, upon written notice of such nonconformity within one year of the date of its shipment from BRINKMANN'S plant, repair or replace such non-conforming material at the original point of delivery. Brinkmann will furnish instructions for disposition of the goods. If, however, Brinkmann provides a written warranty, as to this specific product, which is not in conformity to the above warranty, then as to such specific product, the specific written warranty shall prevail.

In addition to the warranty that this product will conform to the description in Brinkmann's catalog and that any such non-conforming material will be repaired or replaced, as above stated, BRINKMANN further warrants that it conveys good title to this product, free of all liens of any kind whatever unknown to the first Buyer. These are the sole warranties of BRINKMANN with respect to this product. BRINKMANN MAKES NO FURTHER WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS ARE HEREBY DISCLAIMED BY BRINKMANN AND EXCLUDED FROM THIS SALE.

The Buyer's exclusive and sole remedy on account or in respect of the product herein contained that does not conform to the description thereof, or to any express or implied warranty, shall be to secure replacement thereof as aforesaid. BRINKMANN shall not in any event be liable for the cost of any labor expended on any such material or for any special, direct, indirect, incidental or consequential damages to anyone by reason of the fact that such goods do not conform to the description thereof or to any express or implied warranty.